


# AromaArt Glass Essential Oil Diffuser INSTRUCTIONS

## PARTS



## FEATURES

Ultrasonic vibrations transform water and essential oil into a steady stream of aroma-infused mist.

1. Water Capacity: 120 mL (4.06 fl oz)
2. Coverage Area: Up to 40 sq m. (430 sq ft)
3. Continuous Run Time: Up to about 5 hours  
Intermittent Run Time: Up to about 10 hours  
\*Run time will vary depending on humidity levels and other external factors .

4. Light Mode:  
Version1: Rotating color, freeze color, manual light and OFF  
Version2: Bright white light, soft white light and OFF

5. Automatic safety shut-off

6. Power: Certified AC Adapter included

## CARE&MAINTENANCE

Only use the power cord supplied with the unit. Always remove the power cord before cleaning.

Essential oil should not come in contact with the exterior surface of the unit.

TO CLEAN:

Remove Outer Cover. Empty the water from the Water Tank away from the Air Outlet.

The Ceramic Disc should not come in contact with any hard or sharp objects.

To remove possible buildup, gently use a cotton swab dipped in white vinegar to wipe out the inside.

Dry with a soft cloth to avoid mineral buildup.

Do not use strong cleaning agents.

## INSTRUCTIONS FOR USE

1. Remove Glass Cover. Remove Water Tank Lid from the Base.
2. Insert the Adapter's DC connector into the DC Socket located on the bottom of the Base. Plug the AC end of the Adapter into an electrical wall outlet.
3. Pour tap water into the Water Tank up to the Max Water Level Line. Add 2-5 drops of essential oil (not included) directly into the Water Tank.
4. Replace the Water Tank Lid. Replace Glass Cover on top of Base, aligning Mist Outlet with nozzle on Water Tank Lid.

5. Button Functions:

Right Side– Mist:

- Press once to turn on Continuous mist.
- Press twice to turn on Intermittent mist at 30-sec intervals.
- Press three times to turn mist off.

Left Side – Light:

Version1:

- Press once to turn on rotating bright color.
- Press twice to freeze bright color.
- Press three times for manual light mode. With each press of the button the unit will cycle through soft and bright colors, starting from soft green and turning off at bright white.

Notice: At any time, press and hold the button for 3 seconds to turn light off)

Version2:

- Press once to turn on bright white light.
- Press twice to turn on soft white light
- Press three times to turn light off.

6. The unit will stop misting when water level becomes too low. Note that the light must be manually turned off.

7. Disconnect Adapter from electrical outlet when not in use.

